


DRILL_TEMPLATE — PRINT AT 100% ACTUAL SIZE, DO NOT SCALE TO FIT

DockaFi DF0001 — drill template — print at 100% actual size, do not fit to page



■ After printing, measure between the two red dots — must read exactly 40 mm. If not, reprint at Actual Size / 100%.

HOLE SPACING

40 mm

MAX SCREW HEAD

< 10 mm

SCREW TYPE

#8 pan head

INSTALLATION STEPS

- 1 Print at 100% scale.** In your print dialog set scaling to "Actual Size" or 100%. Do not select "Fit to Page."
- 2 Level and tape the template.** Hold the cutout against your mounting surface, use a level to confirm the holes are horizontal, then tape in place.
- 3 Mark both holes.** Press a pencil or awl firmly through each red dot center. Remove the template and pre-drill pilot holes at each mark.
- 4 Install screws and hang.** Drive two screws leaving heads raised 3 to 4 mm from the surface. Slide the DockaFi bracket down over the heads until it seats. Connect power.